



Tech Advice

Condensate And Dripping

Never locate your Immersion Heater in a tank area where the Heater's Terminal Box will come into contact with excessive fumes and dripping. Moisture can AND will work its way into the Terminal Box over time even though HeatStar Systems Immersion Heaters are sealed and (in most cases) NEMA 4X rated.




EXCESSIVE FUMES AND CONDENSATE




MOUNTING YOUR HEATER NEAR OR BY AN EXHAUST INTAKE



DO NOT MOUNT HEATER BELOW TANK RIM



DRIPPING FROM PARTS IN PROCESS



DO NOT OPERATE HEATERS UNDER COVERS AND MAKE SURE THAT THERE IS ADEQUATE VENTILATION